

# UBLink UBS-3024 管理介面基本功能操作設定

## 1. 切 Port VLAN (Multi-to-1 ,記得要 save)

Administrator

Port Management

VLAN Setting

Per Port Counter

QoS Setting

Security

Spanning Tree

Trunking

DHCP Relay Agent

Backup/Recovery

Miscellaneous

Miscellaneous

SNMP Settings

Save Settings

Logout

24-Port 10/100Mbps Modular Fast Ethernet Switch

2 4 6 8 10 12 14 16 18 20 22 24

1 3 5 7 9 11 13 15 17 19 21 23

Multi to 1 Setting

Enable

Destination PortNo

Current Setting

Port 1

Disable Port

Update

1.A example for Multi-to-1 structure

Ports

VLAN Groups

01

1

02

2

:

:

:

M

M

Destination Port/Current Setting

N

1. 記得SAVE,不然重開後會恢復原設定

2. 第幾PORT共用 (圖例為第一PORT共用)

## 2. 每 Port 頻寬控管 (依 32K 或 512K 為基準,參數 1~255,最小 32K\*1~最大 512\*255=130560K=130M)

Administrator

Authentication Configuration

System IP Configuration

System Status

Load default setting

Firmware Update

Reboot Device

Port Management

Port Configuration

Port Mirroring

Bandwidth Control

Broadcast Storm Control

VLAN Setting

Per Port Counter

QoS Setting

Security

Spanning Tree

Trunking

DHCP Relay Agent

Backup/Recovery

Miscellaneous

24-Port 10/100Mbps Modular Fast Ethernet Switch

2 4 6 8 10 12 14 16 18 20 22 24

1 3 5 7 9 11 13 15 17 19 21 23

Bandwidth Control

Port No.

Tx Rate

Rx Rate

Speed Base

Update

Port

Link Speed

Tx Rate(Kbps)

Rx Rate(Kbps)

1

100M

Full Speed

Full Speed

2

100M

Full Speed

Full Speed

3

--

Full Speed

Full Speed

4

--

Full Speed

Full Speed

5

--

Full Speed

Full Speed

6

--

Full Speed

Full Speed

7

--

Full Speed

Full Speed

8

--

Full Speed

Full Speed

9

--

Full Speed

Full Speed

10

--

Full Speed

Full Speed

11

--

Full Speed

Full Speed

1. 可以依32K或512K為單位,做上下傳限制EX:512\*10=5120

### 3.每 Port By MAC 控管(一個 PORT 可設定只有 3 組 MAC 才能過)

24-Port 10/100Mbps Modular Fast Ethernet Switch

2 4 6 8 10 12 14 16 18 20 22 24

1 3 5 7 9 11 13 15 17 19 21 23

Administrator

Port Management

VLAN Setting

Per Port Counter

QoS Setting

Security

MAC Address Binding

MAC Address Scan

TCP/UDP Filter

IP Address Filter

Spanning Tree

Trunking

DHCP Relay Agent

Backup/Recovery

Miscellaneous

Miscellaneous

SNMP Settings

Save Settings

Logout

MAC Address Binding

Port No

MAC Address

00 16 44 3d ff 45

1

Read

Select Port 01 Binding Enable Update

Port No	Filter Status	Port No	Filter Status
1	Enable	13	Disable
2	Disable	14	Disable
3	Disable	15	Disable
4	Disable	16	Disable
5	Disable	17	Disable
6	Disable	18	Disable
7	Disable	19	Disable
8	Disable	20	Disable
9	Disable	21	Disable
10	Disable	22	Disable
11	Disable	23	Disable
12	Disable	24	Disable

可設定哪一個PORT只有那些MAC才能過(意即上網)

PS:也可以做每 Port By IP 控管(By IP 設定最多可以設定 32 組,作法如同 Port By MAC)

### 4.WEB 介面的 load default 會保留 IP&帳號密碼,請特別注意.

24-Port 10/100Mbps Modular Fast Ethernet Switch

2 4 6 8 10 12 14 16 18 20 22 24

1 3 5 7 9 11 13 15 17 19 21 23

Administrator

Authentication Configuration

System IP Configuration

System Status

Load default settings

Firmware Update

Reboot Device

Port Management

VLAN Setting

Per Port Counter

QoS Setting

Security

Spanning Tree

Trunking

DHCP Relay Agent

Backup/Recovery

Miscellaneous

Miscellaneous

SNMP Settings

Save Settings

Logout

Load Default Setting to EEPROM

recover switch default setting excluding the IP Address, User Name and Password

PS:恢復出廠預設值,但會保留設定過後的IP跟密碼,如要恢復完整的預設值,要按機器後面的RESET孔

Load